



www.i-t.su
info@i-t.su

тел: (495) 739-09-95, 739-09-96

ИНТЕРТЕКС
electronics

Линейные передатчики и приемники

Код:	Описание	Корпус
75LBC184	RS 485 TRANSCEIVER	DIP8
ADM202EARN	RS 232 LINEAR DRIVER	SO16
ADM202JN	RS232 DRIVER/RECEIVER HS	DIP16
ADM202JRN-SMD	RS-232 INDUSTRIE	SO16
ADM208EAR	5V RS-232 TRANSCEIVER ESD PROT.	
ADM213ARS	5V POW.CMOS RS232 DR./REC.	SSOP
ADM232LAR	+5V RS-232 DRIVER/RECEIVER	SOL16
ADM232LJN	RS-232 DRIVER/RECEIVER 5V	DIP16
ADM233LJN	5V RS-232 DRIVER/RECEIVER	DIP20
ADM3202ARN	LOW POW 3,3V RS232 DRIVER/RECEIVER	SO16
ADM485AR	RS485 I/R TRANSCEIVER	SO8
ADM485JN	RS485 TRANSRECEIVER	DIP8
ADM485JR-SMD	RS485 TRANSRECEIVER	SOP8
AM26LS31	4*RS422/485 DR 1*ENABLE	DIP16
DS3695N	MULTIP.RS485/RS422	DIP8
HIN232CB	+5V RS232 TRANS/RECEIVER	SOL16
HIN239CB	RS232 TRANS/RECEIVER 5V	SOIC24
ICL232	RS232 TRANSCEIVER	DIP16
ICL232-SMD	RC232 TRANSCEI.SMD SOL16 WIDE	
LT1039CN16	RS232E 3*DRIVER/RECEIVER SHUTDOWN.	DIP16
LT1080CN	TRANSMITTER/RECEIVER RS232C	DIP18
LT1081CN	RS232E 2*DRIVER/RECEIVER LP	DIP16
LT1081IN	RS232E TRANSCEIVER	DIP16
LT1133ACN	RS232E 3*DRIVER/5*RECEIVER LP	DIP24
LT1133ACSW	RS232E 3*DRIVER/5*RECEIVER LP	SOL24
LT1180ACSW	RS232E 2*DRIVER/RECEIVER LP	SOL18
LT1181ACN	2*RS232 DRIVER/RECEIVER LP	DIP16
LT1181ACSW-SMD	RS232E 2*DRIVER/RECEIVER LP	SOL16
LT1181AIN	RS232E 2DRIVER/RECEIVER -40/+85°	DIP8
LTC1321CN	2*RS232E/2*RS485 TRANSCEIVER	DIP24
LTC1334CSW-SMD	4*RS232E/2*RS485 TRANSCEIVER	SOL28
LTC1387CSW	SINGLE 5V RS232/RS485	SO20
LTC1480CS8-SMD	RS485/422 TRANS. 3,3V ULP	SO8
LTC1483CS8-SMD	RS485/422 TRANS. 10kV ESD	SO8
LTC1485CN8	RS485/422 TRANS. 10kV ESD	DIP8
LTC1485CS8-SMD	RS485/422 TRANS. 10kV ESD	SO8
LTC1487CN8	RS485/422 TRANS. ULP	DIP8
LTC1487CS8-SMD	RS485/422 TRANS. ULP	SO8
LTC485CN8	RS485 INTERF.TRANSCEIVER	DIP8
LTC485CS8SMD	RS485 INTERF.TRANSCEIVER	SOP8
LTC486CN	RS485/422 4*DRIVER LP	DIP16
LTC487CS-SMD	RS485/422 4* DRIVER LP	SOL16
LTC488CN	QUAD RS485 LINEAR RECEIVER	DIP16
LTC490CN8	RS485/422 TRANS. LP	DIP8
LTC490CS8-SMD	RS485/422 TRANS. LP	SO8
LTC491CN	DIFF. 2*DRIVER/2*RECEIVER	DIP14
MAX1480ACPI	RS485/RS422 ISOL. INTERFACE	DIP28
MAX1480BCPI	RS485/RS422 ISOL. INTERFACE	DIP28
MAX1480CCPI	RS485/422 DATA INTERFACE ISOL.	DIP
MAX1483CPA	RS485/422 TRANS. 5V 20UA	DIP8
MAX1483ESA	RS485 TRANSCEIVER	SO8
MAX1487CSA	RS485/422 TRANS. 5V	SO8
MAX1487ECPA	RS485/RS422 TRANSCEIVERS	DIP8
MAX1487ECSA	RS485/RS422 TRANSCEIVERS	SO8
MAX1489ECPD	RS232E 4XREC. 15kV ESD	DIP14
MAX1490ACPG	RS485/422 DATA INTERFACE ISOL.	DIP
MAX202CPE	RS-232 TRANSCEIVER	DIP16
MAX202CSE	RS-232 TRANSCEIVER	SO16
MAX202CWE	RS-232 TRANSCEIVER	SO16
MAX202ECPE	RS-232 TRANSCEIVER	DIP16
MAX202ECSE	RS232E 2*DRIVER/RECEIVER 15kV ESD	SO16
MAX202ECWE	RS232E 2*DRIVER/RECEIVER15kV ESD	SOL16
MAX202EPE	RS-232 TRANSCEIVER DIP16	DIP16
MAX206ECNG	RS232E 4*DRIVER/3* RECIIVER15kV ESD	DIP
MAX206ECWG	RS232E 4* DRIVER/3*RECEIVER 15kV ESD	SO24
MAX207ECNG	RS232E 5*DRIVER/3*RECIIVER.15kV ESD	DIP
MAX208CWG	RS232E 4*DRIVER/RECEIVER 5V	SOL24
MAX208ECNG	RS232E 4*DRIVER/RECEIVER 15kV ESD	DIP24
MAX212CWG	RS232E 3*DRIVER/5*RECEIVER 3V	SOL24
MAX214CPI	RS232E TRANS. PROGR. 5V	DIP28
MAX218CPP	RS232E 2*DRIVER/RECEIVER 1,8-4,2V	DIP20
MAX218CWP	RS232E 2*DRIVER/RECEIVER 1,8-4,2V	SOL20
MAX220CPE	RS232E 2*DRIVER/RECEIVER 5V	DIP16
MAX222CPN	RS232E 2*DRIVER/RECEIVER 5V	DIP18
MAX222CWN	RS232 DRIVER/RECEIVER	SOL18
MAX222EWN	RS232 DRIVER/RECEIVER	SOL18
MAX225CWI	RS232 DRIVER/RECEIVER	SOL28

Программа поставок компании TME



www.i-t.su
info@i-t.su

тел: (495) 739-09-95, 739-09-96

ИНТЕРТЕКС
electronics

Код:	Описание	Корпус
MAX230CPP	RS232E 5* DRIVER 5V	DIP16
MAX230CWP	RS232E 5*DRIVER 5V	SOL16
MAX231CPD	2*TRANSMITTER/RECEIVER RS232	DIP14
MAX232ACPE	RS232E 2*DRIVER/RECEIVER 5V	DIP16
MAX232ACSE	RS232 DRIVER/RECEIVER	SO16
MAX232ACWE	RS232E 2*DRIVER/RECEIVER 5V	SOL16
MAX232AEPE	RS232E 2*DRIVER/RECEIVER -40/+85°C	DIP16
MAX232AESE	RS232 DRIVER/RECEIVER	SO16
MAX232AEWE	RS232 DRIVER/RECEIVER	SOL16
MAX232CPE	RS232 RECEIVER/TRANSMITTER MAXIN	DIP16
MAX232CSE	RS232E 2*DRIVER/RECEIVER 5V	SO16
MAX232ECEPE	RS232E 2*DRIVER/RECEIVER 15kV ESD	DIP16
MAX232ECSE	RS232 RECEIVER/TRANSMIT. -40/+85°C	SO16
MAX232EEPE	RS232E 2*DRIVER/RECEIVER -40/+85°C	DIP16
MAX232EWE	RS232 DRIVER/RECEIVER	SO16
MAX233ACWP	RS232 DRIVER/RECEIVER	SOL20
MAX233AEWP	RS232 DRIVER/RECEIVER	SOL20
MAX233CPP	RS232 DRIVER/RECEIVER	DIP20
MAX233EPP	RS232 DRIVER/RECEIVER	DIP20
MAX235CPG	RS232 DRIVER/RECEIVER	DIP24
MAX235EPG	RS232 DRIVER/RECEIVER	DIP24
MAX238CNG	RS232 DRIVER/RECEIVER	DIP24
MAX2402EAP	TRANSMITTER 0,8-1GHZ -40/+85°C	SSOP20
MAX241ECWI	+15kV ESD-PROTEC. 5V RS232	SO28
MAX242CWN	RS-232 DRIVER/RECEIVER	SO16
MAX250CPD	RS232E 2*DRIVER/RECEIVER ISOL 5V	DIP14
MAX250CSD	RS232E 2*DRIVER/RECEIVER ISOL. 5V	SO14
MAX251CPD	RS232E 2*DRIVER/RECEIVER ISOL. 5V	DIP14
MAX251CSD	RS232E 2*DRIVER/RECEIVER ISOL. 5V	SO14
MAX253CPA	TRANSF. DRIVER FOR ISOL. RS485	DIP8
MAX3080CPD	RS485/422 TRANSC. HS	DIP14
MAX3082CPA	RS485/422 TRANSC. HS	DIP8
MAX3089CSD	RS485/422 TRANSC. HS	SO14
MAX3095CPE	RS485/422 4*RECEIVER 15kV ESD	DIP16
MAX3120CSA	IRDA-TRANSCEIVER 3-5,5V 120UA	SO8
MAX3131CAI	IRDA-TRANSCEIVER+RS232-INTERFACE	SSOP
MAX3221ECAE	RS232E DRIVER/RECEIVER 15kV ESP	SSOP
MAX3221EEAE	RS232 TRANSREC. 15kV PROT.	SO16
MAX3222CPN	LOW POWER RS232 2*DRIVER/RECEIVER	
MAX3223CPP	RS232E 2*DRIVER/RECEIVER 3-5,5V	DIP20
MAX3226ECAE	RS232E TRANSCEIVER 15kV ESD	SOP16
MAX3226EEAE	250KBPS RS232 TRANSCEIVER	SOP16
MAX3232CPE	3,5-5V LOW POWER TRANREC.	DIP18
MAX3232CSE	RS232 TRANSCEIVER 15kV	SO18
MAX3232EEWE	2*DRIVER/RECEIVER RS232 TR./REC.	SO16
MAX3232ESE	2*DRIVER/RECEIVER RS232 TR./REC.	SO18
MAX323CPA	2*SPST ANALOG SWITCH <60R	DIP8
MAX3245ECAI	RS232E 3*DRIVER/5*RECEIVER 15kV ESD	SSO
MAX3471CUA	RS485/422 TRANSCEIVER 1,6UA uMAX8	
MAX3471EVA	RS-485/RS-422 HALF DUPLEX 8MAX	
MAX3483CPA	RS485/422 TRANSCEIVER 3,3V	DIP8
MAX3485CPA	RS485/422 TRANSCEIVER 3,3V	DIP8
MAX4144ESD	DIFF LINE-RECEIVER 30MHZ	SO14
MAX481CPA	RS485/422 TRANSCEIVER 5V	DIP8
MAX481CSA	RS485/422 TRANSCEIVER 5V	SO8
MAX481ECPA	RS485/422 TRANSCEIVER 15kV ESD	DIP8
MAX481EESA	RS-485/RS-422 TRANSCEIVER	SO8
MAX483CPA	RS-485/RS-422 TRANSCEIVER	DIP8
MAX483CSA	RS485/422 TRANSCEIVER 5V	SO8
MAX483ECPA	RS-485/RS-422 TRANSCEIVER	DIP8
MAX483ECSA	RS-485/RS-422 TRANSCEIVERS	SO8
MAX485CPA	RS-485/RS-422 TRANSCEIVER	DIP8
MAX485CSA	RS-485/RS-422 TRANSCEIVER	SO8
MAX485ECPA	RS485/422 TRANSCEIVER 15kV ESD	DIP8
MAX485ECSA	RS-485/RS-422 TRANSCEIVER	SO8
MAX487CPA	RS485/422 TRANSCEIVER 5V	DIP8
MAX487CSA	RS485/422 TRANSCEIVER 5V	SO8
MAX487ECPA	RS485/422 TRANSCEIVER 15kV ESD	DIP8
MAX487ECSA	RS485/422 TRANSCEIVER 15kV ESD	SO8
MAX487EPA	TRASCEIVER RS485/RS422	DIP8
MAX488CPA	RS485/RS422 TRANSMITTER/RECEIVER	DIP
MAX488CSA	RS485/RS422 TRANSMITTER/RECEIVER	SO8
MAX489CPD	FULL DUPL. RS485 TRANSCEIVER	DIP14
MAX489ECSA	RS485/RS422 TRANSMITTER/RECEIVER	SO14
MAX490CSA	RS485/RS422 TRANSCEIVER	SO8
MAX490ECPA	RS485/422 TRANSCEIVER 15kV ESD	DIP8
MAX491CPD	RS485/422 TRANSCEIVER 5V	DIP14
MAX491CSD	RS485/422 TRANSCEIVER 6V	SO14
MAX491ECPD	RS485/422 TRANSCEIVER 15kV ESD	DIP14
MC10116P	TRIPLE LINE RECEIVER	DIP16



www.i-t.su
info@i-t.su

тел: (495) 739-09-95, 739-09-96

ИНТЕРТЕКС
electronics

Код:	Описание	Корпус
MC145406P	RS 232-C/V 28 DRIVER/RECEIVER	DIP16
MC1488	QUAD RS232 DRIVER	DIP14
MC1488D	QUAD RS232 DRIVER	SOP14
MC1489	QUAD RS232 RECEIVER	DIP14
MC1489AP	QUAD LINE RECEIVER	DIP14
MC1489D	QUAD RS232 RECEIVER	SO14
MC3486	QUAD RS422/3 RECIVER	DIP16
SN65176BP	SINGLE RS422/485 TRANSCEIVER	DIP8
SN75110	DIFF. DRIVER TRANSMITTER	DIP14
SN75172N	4*DIFFERENTIAL LINE DRIVER	DIP16
SN75173N	4*DIFFERENTIAL LINE RECEIVER	DIP16
SN75174N	4*RS422A/485 RECEIVER 5V	DIP16
SN75175N	4*RECEIVER RS422A/RS485	DIP16
SN75176	BUS/LINE TRANSCEIVER	DIP8
SN75176-SMD	BUS/LINE TRANSCEIVER	SO8
SN75179	RECEIVER/TRANSMITTER RS422	DIP8
SN75976A1DL	9-CHANAL. RS-485 TRANSCEIVER	SSOP56
SN75C189N	QUADRUPLE RS232 RECEIVER	DIP14
SN75LBC176D	RS485 TRANSCEIVER CMOS	SO8
SO42P	MIXER 200MHZ	DIP14
ST232ACD	LOW POW. CONSUMP. 5V RS232	SO16
ST3232CD	3/5,5V LOW POW. RS232 DRIVER/RECEIV.	SO16
ST7537HS1CFN	HALF DUP. ASYNCH. 2400BPS	PLCC28
ST7538P	POWER LINE FSK TRANSCEIVER	TQFP44
TL16C554FN	4*TRANSRECEIVER	PLCC68
UA9636ACP	2-FACH RS 423 LINEAR DRIVER	DIP8
UA9637ACP	DUAL DIFFERENT. LINE RECEIVER	DIP8